

BOTOX CHECKLIST

- A. Check urinalysis if negative
- B. Place foley catheter
- C. Instill 20 mL of 1% lidocaine and clamp
- D. Reconstitute botox with preservative free saline.
- E. Assemble cystoscopy equipment
- F. Drain bladder and flush with 30cc sterile saline
- G. Remove foley

200 Unit Vial of BOTOX

1. Reconstitute a 200 Unit vial of BOTOX with 6 mL of 0.9% non-preserved saline solution and mix the vial gently.
2. Draw 2 mL from the vial into each of three 10 mL syringes.
3. Complete the reconstitution by adding 8 mL of 0.9% non-preserved saline solution into each of the 10 mL syringes, and mix gently. This will result in three 10 mL syringes each containing 10 mL (~67 Units in each), for a total of 200 Units of reconstituted BOTOX.
4. Use immediately after reconstitution in the syringe. Dispose of any unused saline.

100 Unit Vial of BOTOX

1. Reconstitute two 100 Unit vials of BOTOX, each with 6 mL of 0.9% non-preserved saline solution and mix the vials gently.
2. Draw 4 mL from each vial into each of two 10 mL syringes. Draw the remaining 2 mL from each vial into a third 10 mL syringe for a total of 4 mL in each syringe.
3. Complete the reconstitution by adding 6 mL of 0.9% non-preserved saline solution into each of the 10 mL syringes, and mix gently. This will result in three 10 mL syringes each containing 10 mL (~67 Units in each), for a total of 200 Units of reconstituted BOTOX.
4. Use immediately after reconstitution in the syringe. Dispose of any unused saline.